


INSTRUCTIONS FOR INSTALLATION

Kabe Combi Mat

Generally speaking, all types of mat should always be laid on a level, solid surface.


1. On existing floor

If the mat lies on an incline or steps, it is best to insert studs in the floor or steps to prevent the mat from slipping.



2. On existing floor

Mats can be provided with Kabe Mat Ramp type 1 on the ends to prevent the risk of tripping.



3. On existing floor

If the mat lies against a doorsill or step, a Kabe Mat Ramp type 1 can be fitted to the front edge.




4. Recessed surface on existing floor

Kabe Mat Ramp type 2 on all four sides of the mat. The ramp is not attached to the mat and should be screwed to the floor if possible.




5. Recessed surface on existing floor

Kabe Mat Ramp type 2 can be placed on two or three sides if the mat lies against a doorsill or step. Ramps should be securely screwed to the floor.




6. In a mat well

The mat should be recessed 20 - 22 mm. The Kabe casting frame is recommended to protect surrounding floor edges.




7. Existing mat well

If the recess is 15-19 mm deep, use Kabe Mat Original, height 18 mm. If a mat is placed in a well of less than 15 mm, fit Kabe special ramps at both ends.



8. Drainage in the mat well

Kabe drains have an effective sand separator. With or without water trap.



9. Mats over drainage grids

To achieve a self-cleaning effect, place the mat on a Kabe drainage grid in a deeper recess.

